
15EEE337 Digital Image Processing

Sarath T.V.

Last Lecture

- Image restoration
- mage denoising




Degradation function estimation

- Image restoration process
- Image restoration considering only noise.
- Degradation function.
- Three ways to estimate the degradation function
 - Observation
 - Experimentation
 - Mathematical modeling
- Blind convolution True degradation function is rarely known completely.

Estimation by Image Observation


- Gather information from the image itself.
- Look for area in the signal content is strong- Reducing the effect of noise.



$$G(u, v) = H(u, v)F(u, v) + N(u, v)$$

Estimation by Experimentation

- Equipment similar to the one used for acquiring the degraded image
- Changing system setting acquiring images – as close as to the image we want to restore.
- Underlying idea- obtain the impulse response of degradation
- Small dot of light as bright as possible.



Estimation by modeling


• Model can consider the environmental conditions also.



Inverse filtering

- The simplest approach to restoration is direct inverse filtering,
- where we compute an estimate of the transform of the original image by dividing the transform of the degraded image

$$\hat{F}(u,v) = \frac{G(u,v)}{H(u,v)}$$



 $H(u,v) = e^{-k[(u+M/2)^2+(v-N/2)^2]^{5/6}}$

Min Mean Square Error Filtering

- Image and noise –Random variable
- Error keep it minimal.

$$e^2 = E\left\{ (f - \hat{f})^2 \right\}$$

